



Ball and Roller Bearings

TECHNICAL EXPLANATION CONTENTS

<p>1. Classification and characteristics of rolling bearings A-4</p> <p>1.1 Structure A-4</p> <p>1.2 Classification A-4</p> <p>1.3 Characteristics A-8</p> <p>2. Bearing selection A-14</p> <p>2.1 Bearing selection flow chart A-14</p> <p>2.2 Type and characteristics A-16</p> <p>2.3 Selection of bearing arrangement A-17</p> <p>3. Load rating and life A-20</p> <p>3.1 Bearing life A-20</p> <p>3.2 Basic rating life and basic dynamic load rating A-20</p> <p>3.3 Adjusted rating life A-22</p> <p>3.4 Modified rating life A-24</p> <p>3.5 Machine applications and requisite life A-27</p> <p>3.6 Weibull distribution and life adjustment factor for reliability A-28</p> <p>3.7 Misalignment angle (installation error) and life A-29</p> <p>3.8 Clearance and life A-30</p> <p>3.9 Basic static load rating A-30</p> <p>3.10 Allowable static equivalent load A-31</p> <p>3.11 Allowable axial load A-31</p> <p>3.12 Review of basic dynamic load ratings A-33</p> <p>3.13 Bearing life calculation tool A-33</p> <p>4. Bearing load calculation A-34</p> <p>4.1 Load acting on shafts A-34</p> <p>4.2 Bearing load distribution A-39</p> <p>4.3 Mean load A-40</p>	<p>4.4 Equivalent load A-41</p> <p>4.5 Bearing rating life and load calculation examples A-43</p> <p>5. Boundary dimensions and bearing number codes A-46</p> <p>5.1 Boundary dimensions A-46</p> <p>5.2 Bearing numbers A-48</p> <p>6. Bearing tolerances A-54</p> <p>6.1 Dimensional and rotational accuracy A-54</p> <p>6.2 JIS terms A-56</p> <p>6.3 Chamfer measurements and tolerance or allowable values of tapered bore A-70</p> <p>6.4 Bearing tolerance measurement methods A-72</p> <p>6.5 Geometrical product specifications (GPS) A-73</p> <p>7. Bearing fits A-75</p> <p>7.1 Resultant fits A-75</p> <p>7.2 The necessity of a proper fit A-75</p> <p>7.3 Fit selection A-76</p> <p>8. Bearing internal clearance and preload A-88</p> <p>8.1 Bearing internal clearance A-88</p> <p>8.2 Selection of internal clearance A-88</p> <p>8.3 Preload A-100</p> <p>8.4 Necessary minimum load A-104</p> <p>9. Allowable speed A-106</p> <p>9.1 Constant speed rotation A-106</p>	<p>9.2 Low-speed rotation and rapid acceleration/deceleration A-107</p> <p>9.3 Oscillating applications A-107</p> <p>9.4 Heat rating rotational speed A-108</p> <p>10. Friction and temperature rise A-109</p> <p>10.1 Friction A-109</p> <p>10.2 Temperature rise A-109</p> <p>10.3 Starting torque calculation A-110</p> <p>11. Lubrication A-111</p> <p>11.1 Purpose of lubrication A-111</p> <p>11.2 Lubrication methods and characteristics A-112</p> <p>11.3 Grease lubrication A-112</p> <p>11.4 Solid grease A-119</p> <p>11.5 Oil lubrication A-120</p> <p>12. External bearing sealing devices A-124</p> <p>13. Bearing materials A-128</p> <p>13.1 Raceway and rolling element A-128</p> <p>13.2 Cage A-131</p> <p>13.3 Rubber seal materials A-132</p> <p>13.4 Periphery of bearing (shaft, housing) A-132</p> <p>13.5 NTN bearings with prolonged life A-132</p> <p>13.6 Bearing fatigue analysis technique A-139</p> <p>14. Shaft and housing design A-146</p> <p>14.1 Fixing of bearings A-147</p> <p>14.2 Bearing fitting dimensions A-148</p>	<p>14.3 Shaft and housing accuracy A-149</p> <p>14.4 Bearing permitted inclination/allowable alignment angle A-149</p> <p>15. Bearing handling A-150</p> <p>15.1 General information A-150</p> <p>15.2 Bearing storage A-150</p> <p>15.3 Bearing installation A-152</p> <p>15.4 Lubricant enclosure A-161</p> <p>15.5 Post installation running test A-161</p> <p>15.6 Bearing disassembly A-161</p> <p>15.7 Bearing maintenance and inspection A-164</p> <p>15.8 Bearing maintenance tools A-168</p> <p>16. Bearing damage and corrective measures A-170</p> <p>16.1 Bearing damage, main causes of bearing damage, and remedies for correcting the problem A-170</p> <p>16.2 Rolling paths and how load is applied A-176</p> <p>17. Technical data A-178</p> <p>17.1 Radial internal clearances vs. axial internal clearances A-178</p> <p>17.2 Axial load vs. axial displacement A-183</p> <p>17.3 Allowable axial load A-187</p> <p>17.4 Fitting surface pressure A-188</p> <p>17.5 Necessary press fit and pullout force A-190</p> <p>17.6 Bearing technique calculation tool A-190</p>
---	--	---	---